




STEP 1 - ESTABLISH BASE COURSE, USING NORMAL CONSTRUCTION PROCEDURES, AS SHOWN ON WALL PLAN.




STEP 2 - ADD SECOND COURSE OF STEP UNITS, MAINTAINING RUNNING BOND. OVERLAP PREVIOUS COURSE OF STEP UNITS 2, AND AFFIX TO LOWER COURSE WITH AN EXTERIOR CONSTRUCTION ADHESIVE.




STEP 3 - CONTINUE TO PLACE THE NEXT COURSE OF DIAMOND® UNITS ON THE WALL, MAINTAINING THE RUNNING BOND. CUT THE UNIT MARKED WITH "X" TO FIT, REMOVE THE REAR LIP OF THIS UNIT AND AFFIX WITH AN EXTERIOR CONSTRUCTION ADHESIVE.



STEP 4 - PLACE THE NEXT ROW OF STEP UNITS. OVERLAP THE PREVIOUS COURSE 2 INCHES, AND AFFIX WITH AN EXTERIOR CONSTRUCTION ADHESIVE. EXTEND THIS COURSE BEHIND THE WALL SYSTEM AS NEEDED.



STEP 5 - CONTINUE STEPS 3 AND 4 UNTIL THE DESIRED WALL HEIGHT IS COMPLETED. CUT THE BLOCK SHOWN AS "X", REMOVE THE REAR LIP AND AFFIX THE BLOCK WITH AN EXTERIOR CONSTRUCTION ADHESIVE FOR EACH COURSE CONSTRUCTED.



Anchor Wall Engineering, LLC
5959 Baker Road, Suite 390
Minnetonka, MN 55345

These graphic representations are intended for preliminary design purposes only and are not to be used for construction without the signature of a registered professional engineer.

©2008 Anchor Wall Engineering, LLC
® and ™ Anchor Wall Systems, Inc.

Drawn By: AWE
Date: 3/18/2008
Scale: 3/8"=1'-0"

Drawing Title:
Project Information:

Diamond® Retaining Walls
Typical Stair Construction

Typical Retaining Wall Details
www.anchorwall.com